



VIDEO DOORBELL

Setup and Installation Guide



English



To download the Ring app visit:
ring.com/app


The Ring app will walk you through setting up your Ring Doorbell.



To watch videos on installing and getting started with your Ring Video Doorbell, visit:

ring.com/setup

The Back of Your Ring Doorbell 1



Setup Button

The orange button on the back of your Ring Doorbell is the **setup button**. You'll be instructed to push this button during the in-app setup process.

Charging Port

If you're not wiring your Ring Doorbell, you'll need to charge it periodically by plugging the provided orange cable into the charging port.

In-app Setup 2

Set Up Your Ring Doorbell Using the Ring App

The Ring app will walk you through the setup process.



Download the Ring app by visiting ring.com/app and when prompted, select **Video Doorbell**.

i Perform setup inside near your router. **You'll need your network name and Wi-Fi password.**

Network Name: _____

Wi-Fi Password: _____

Testing Your Ring Doorbell 3

Push the Front Button to Run a Test

After setup, push the front button on your Ring Doorbell **indoors near your router** to see video from your Ring Doorbell in the Ring app.



Then test your Ring Doorbell outside.

i If video quality from your Ring Doorbell is not as good outdoors as it is indoors, you may need to move your router closer to your door, or invest in a Wi-Fi extender.

Learn more at: ring.com/extender

Installation 4

Remove Your Existing Doorbell (optional)

If you're replacing a wired doorbell, first turn off the power at the breaker.



Then remove your doorbell from the wall, and disconnect the wires.

i If you notice a diode when you remove your wired doorbell, take note of this, as it means you will need to use the included diode.



Installation 5

Install the Mounting Bracket

Take everything that came in the box, along with a power drill if you're installing on **stucco, brick, or concrete**, to the spot where you'll be installing your Ring Doorbell.


Snap the provided level onto the mounting bracket and use it to help position the bracket.



Then **remove the orange tape**, and use the mounting bracket as a template to mark the four corner holes.

Installation 6

On **stucco, brick, or concrete** install the anchors using the provided drill bit and a power drill before installing the mounting bracket.



On **wood or siding**, you can skip this step, and screw the bracket directly into your wall.


Installation 7

Use the Phillips head side of the Ring screwdriver for screwing in your mounting bracket.



Installation 8


Drive the screws into the anchors, or directly into your wall until they are flush with the mounting bracket, and the bracket is flat against your wall.



If your wall is at all uneven, be careful not to screw the bracket in so tightly that it bends.

Connect the Wires (optional)

Connect the wires coming out of your wall to the screws on the bracket.



It doesn't matter which wire connects to which screw.

i If you're replacing an existing doorbell, the wiring must be connected to a transformer with a voltage of **8VAC – 24VAC** and an internal doorbell or resistor.

DC transformers and (therefore) most intercoms are not supported.

How and When to Use the Diode

If your doorbell is digital (e.g. plays a melody), attach the included diode to the two screws on your bracket.

If your doorbell is mechanical (e.g. goes "ding-dong"), **DO NOT USE THE DIODE.**




i If you have a **digital doorbell**, connecting the diode the wrong way won't do any harm. If your existing doorbell doesn't ring, just reverse the diode.

Learn more at: ring.com/diode

Attach Your Doorbell to the Bracket


Line up the holes in your Ring Doorbell with the slots on the bracket.

Push firmly towards the wall and then down until you feel a click.

**Secure Your Ring Doorbell**

Use the star-shaped end of your Ring screwdriver to tighten the **security screws** on the bottom of your Ring Doorbell.

Then restore power at the breaker.

**Congratulations!**

 You've successfully set up your Ring Doorbell. Push the front button to try it out.

Shared Users

 To give others, such as family or friends access to your Ring Doorbell, select **Shared Users** in the Ring app, and enter their email(s). Shared users can answer live events and view recordings.

Motion Detection

 To enable and customise motion detection, select **Motion Settings** in the Ring app.

The front light on your Ring Doorbell uses a number of patterns to communicate messages.

Here are some common ones.

Wired  White Solid


Front Button Pushed  Blue Spinning

Ring Speaker Enabled  Blue Solid

Charging  Charge Percentage

In Setup Mode  White Spinning

Updating software  White Flashing



When someone is at your door, you can:

 Disable/enable your microphone  Zoom in/out
 Mute/unmute your speaker  Access the Ring Plus menu

Turning alerts on or off:

Select your Ring Doorbell on the homescreen of the app to change your alert settings.

RING ALERTS 

MOTION ALERTS 

**Cloud Video Recording**

This optional premium feature saves events captured by your Ring Doorbell.

You can access these events on any device running the Ring app, or at: ring.com/activity

To learn more about **Cloud Video Recording**, visit:

ring.com/cloud-recording

**Ring Chime**

Ring Chime is an optional add-on that alerts you when you have a visitor, even if your phone is in the other room.

Learn more at:

ring.com/chime

For additional help, visit: ring.com/help

For immediate assistance, we're available 7 days a week at:

+1 310-929-7085

help@ring.com

ring

1523 26th St.
Santa Monica,
CA 90404

CE 0682

Hereby, Bot Home Automation, declares that this consumer electronic is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at www.ring.com/DoC.pdf.

Protect the device from direct sunlight. Install the device at dry locations and protect it against rain and humidity. The device may not get contact to salt water or other conductive liquids. The device must be charged only within a building in a dry state.

© 2016 Bot Home Automation, Inc.

RING, ALWAYS HOME, and CHIME are trademarks of Bot Home Automation, Inc.

Last updated: 01/28/16